

CARECLEAN SEPARATOR

Acid cleaning agent for cleaning stainless steel separator discs and separator bowl.

- * A strong cleaning agent specially developed for cleaning stainless steel separator discs.
- * Contaminants found on separator discs mostly consists of hardness salts (calcium carbonate etc.) and partly carbonised oil. The combination of dissolving agents, acids and surface active agents makes it possible to clean the separator discs quickly without brushing.
- * After cleaning the metal surface is passivated by the acid of the product.

Directions for use

Careclean Separator can only be used for cleaning stainless steel separator discs. Fill a stainless steel or plastic container with pure Careclean Separator. Immerse the stainless steel discs in the container and let the product act for 30 minutes up to a maximum of 2 hours. Heating the product is not necessary. Do not put the discs closely packed into the liquid but take care that there is enough space between them so that the product can work properly. Remove the discs from the bath (wear rubber gloves) and rinse with a powerful waterjet. The cleaned separator discs can be used immediately.

Properties

Careclean Separator is a colorless, strong acid, liquid cleaning agent with strong degreasing properties. This product can only be used on austenitic stainless steel and is corrosive on all other metals.

Specific Gravity (20°C)	: 1,036
Flash point	: None
pH (1% solution)	: 1.8

For detailed information on safety and health, please refer to Material Safety Data Sheet and / or Product label.

The details of our products are given completely free of undertaking. Since their application lies outside our control we cannot accept any liability for the result.